

Instructions for Installing the Wall-Mount Cabinet

read completely before beginning installation

NOTE: It is best to mount cabinet on wall studs, if possible. Use the 1-1/2" screws without anchors and omit Steps 2 and 5, below. If the cabinet cannot be attached at the studs, use the 1" screws with anchors; follow Steps 1 through 6 below.

- 1 Select two of the four slotted holes near the top of the cabinet, either 16" or 24" on center. Mark the wall for these two holes by careful measurement or by holding the cabinet temporarily in the correct position on the wall. *See A.*
- 2 At these two locations, drive the pointed end of an anchor into the wall by tapping with a hammer until each is snug to the wall. *See B.*
- 3 Install the cabinet using the correct size screws (read **NOTE**, above). **Do not tighten screws if using wall anchors.**
- 4 Mark the center of the bottom holes, as in Step 1.
- 5 Remove the cabinet and install two bottom anchors, as in Step 2.
- 6 Permanently install the cabinet using same-size screws at all four locations (read **NOTE**, above). Tighten all screws. *See C.*

