

COLOR COMPARISON TEST ORTHOPHOSPHATE

COMPONENTS:

2-STANDARD COMPARATORS*: RANGE:

9025	(30 & 60 ppm)
9026	(20 & 40 ppm)
9028	(20 & 60 ppm)
9030	(40 & 80 ppm)

*Kit may include only one comparator.

REAGENTS:

R-0601-C	Molybdate Reagent*, 2 oz
R-0602P-I	Stannous Chloride Powder, 10 g

APPARATUS:

2 x 2269	Cap, Dispenser, 18 mm, white
1 x 4027	Funnel, 58 mm, plastic
1 x 5210	Instruction
1 x 6003	Brush, Test Tube
1 x 6009	Filter Paper, 9.0 cm, #610, 100/box
1 x 9021	Test Tube, Mixing, Calibrated (5, 10, 14, 15, 17.5 mL), glass w/stopper

TO ORDER REPLACEMENT PARTS AND REAGENTS CALL TOLL-FREE
800-TEST KIT (800-837-8548).

PROCEDURE:

CAREFULLY READ AND FOLLOW PRECAUTIONS ON REAGENT LABELS.
KEEP REAGENTS AWAY FROM CHILDREN.

Instr. #5210

Orthophosphate Test

1. Filter water to be tested to clarify.
2. Rinse and fill test tube (#9021) to 5 mL mark with filtered sample.
3. Cap R-0601 Molybdate Reagent with dispenser cap (#2269). Add R-0601 Molybdate Reagent to 15 mL mark. Stopper and mix. Remove stopper.
4. Add 2 level dippers R-0602P Stannous Chloride Powder. Stopper and mix.
5. Wipe dry and place in comparator. WAIT 1 MINUTE. Read before 5 minutes.
6. Match color in test tube with a color standard. Record as parts per million (ppm) orthophosphate (PO_4^{3-}).

*WARNING: Molybdate Reagent R-0601 contains 5-10% w/w sulfuric acid, a corrosive acid.



31 Loveton Circle, Sparks, MD 21152 USA
800-TEST KIT (837-8548) • 410-472-4340

011018