

Chlorine F&T DPD/P 8

Range(s): 0-8.0 ppm Cl_2



Procedure

Note: When testing multiple samples simultaneously, a separate sample cell with an unreacted sample of the water tested must be used to zero the colorimeter. Please note that varying the test procedure from the original can affect the precision of the test.

1. Turn on the Colorimeter.
2. Select a test menu (ALL TESTS, RECENT TESTS, or FAVORITES) containing Chlorine F&T DPD/P 8 using ◀▶.
3. Select Chlorine F&T DPD/P 8 using ▲▼; then press ENTER Ⓢ.
4. Rinse and fill 15 mm sample cell to 5 mL mark with sample; then cap.
5. Insert sample cell into sample cell compartment. Align marks per User's Manual.
6. Select ZERO using ◀▶; then press ENTER Ⓢ. Zero will be displayed.

7. Remove sample cell from sample cell compartment; then remove cap.
8. Using the 0.15 g dipper spoon, add 1 level dipper Chlorine F&T DPD/P - Reagent A; then cap and swirl to dissolve powder.
9. Insert sample cell into sample cell compartment. Align marks.
10. Select READ using ◀▶; then press ENTER Ⓢ. The instrument will read the sample and the result will be displayed. Record reading as free chlorine (FC) as Cl_2 .

To determine the concentration of total chlorine (TC) as Cl_2 proceed to the following steps.

11. Remove sample cell from sample cell compartment; then remove cap.
12. Add 5 drops Chlorine F&T DPD/P - Reagent B; then cap and swirl to mix thoroughly.
13. Insert sample cell into sample cell compartment. Align marks.

14. Select READ using ◀▶; then press ENTER Ⓢ. The instrument will read the sample and the result will be displayed. Record reading as total chlorine (TC) as Cl_2 .

Note: When testing for total chlorine in wastewater, *Standard Methods for the Examination of Water and Wastewater* recommends a 2-minute wait time for full color development. To include a 2-minute wait time, omit step 14 above and continue with the following steps:

14. Select TIMER using ◀▶; then press ENTER Ⓢ.
15. Select START using ◀▶; then press ENTER Ⓢ. (A 2-minute [02:00] countdown will begin.) Immediately select AUTO using ◀▶; then press ENTER Ⓢ.
16. When the timer beeps, the instrument will read the sample and the result will be displayed. Record reading as total chlorine as Cl_2 .

Interferences

Alkalinity, Total (CaCO_3) > 200 ppm – negative interference

To remove interference: Fill dilution vial to 50 mL mark and adjust pH to 6-7 with Sulfuric Acid N (R-0686). Take a 10 mL portion and follow test procedure above.

Bromine, all levels – positive interference

Chlorine Dioxide, all levels – positive interference

Hardness, Calcium (CaCO_3) > 1000 ppm – negative interference

Iodine, all levels – positive interference

Manganese, all levels – positive interference

Monopersulfate, all levels – positive interference

Ozone, all levels – positive interference

Interferences (continued)

The following analytes were tested to the levels listed and found not to cause any interference up to the specified values:

Azole (BT) – 5 ppm
Azole (TT) – 5 ppm
Biguanide (as product) – 50 ppm
Chloride – 1000 ppm
Copper – 5 ppm

Cyanuric Acid – 200 ppm
Fluoride – 10 ppm
Hydrogen Peroxide – 30 ppm
Iron, Ferric – 10 ppm
Iron, Ferrous – 10 ppm
Molybdate – 10 ppm
Nitrate – 2000 ppm
Nitrite – 2000 ppm

Instruction #5528

Phosphate – 100 ppm
Phosphonate – 20 ppm
Polymer – 1000 ppm
Polyphosphate – 5 ppm
Silica – 150 ppm
Sulfate – 1000 ppm
Sulfite – 100 ppm
Zinc – 5 ppm

Test Method

DPD (N,N-diethyl-p-phenylenediamine)

Free chlorine, in the form of hypochlorous acid or hypochlorite ion, reacts with DPD to produce a magenta-colored compound with an intensity that is proportional to the concentration of free chlorine in a sample. Iodide ion, added subsequently, reacts with any chloramines present to form iodine, which then reacts with DPD to increase the intensity of the color proportional to the concentration of chloramines in a sample.

Estimated Detection Limit

0.1 ppm Cl₂

Precision

Using two lots of reagent and a standard solution of 5 ppm Cl₂, an individual analyst obtained a standard deviation with the instrument of ± 0.05 ppm Cl₂.

Application

Industrial Water, Potable Water, Recreational Water, and Wastewater

Ordering Info

Reagent Pack

K-8001 Chlorine F&T DPD/P 8
Formulated for exclusive use with Taylor's TTi® Colorimeter.

Reagent Pack Components

R-8001A Chlorine F&T DPD/P - Reagent A
R-8001B Chlorine F&T DPD/P - Reagent B

Optional Reagents & Accessories

R-0686 Sulfuric Acid N



31 Loveton Circle, Sparks, MD 21152 U.S.A.
800-TEST KIT (837-8548) • 410-472-4340
customerservice@taylortechnologies.com