

# Counterlab Rx 2™ Assembly / FAS-DPD Method

1. Remove lab (#9014), all reagents, and all parts from boxes and plastic bags.
2. Set lab on flat, level surface near electrical outlet.
3. Thread correct AC Power Adapter (#6089) through interior then through hole in front of back wall of lab and connect to Gepe Slim Lite™ (#9199). Place Slim Lite inside brackets as shown below.
4. Thread correct AC Power Adapter (#6525) through interior then through hole in middle of lab and connect to SpeedStir® magnetic stirrer (#9280). Place SpeedStir between pins as shown below.

**Important:** AC power adapters are not interchangeable.

5. Open DPD Powder vial (R-0870) and snap Unit Dose Dispenser™ (#9250) onto top of vial. Snap vial lid onto notch located on side of Unit Dose Dispenser.
6. Place reagents (R-0003 to R-0871) in openings according to labels:
 

<b>Top left</b> R-0870*, R-0871*, R-0003	<b>Top right</b> R-0007, R-0008, R-0009
<b>Bottom left</b> R-0004, R-0005, R-0006	<b>Bottom right</b> R-0010, R-0011L, R-0012
7. Screw 28 mm dispenser cap (#2280) on R-0013 and R-0833.
8. Place R-0013 and R-0833 into large openings at sides of lab.
9. Place CYA cylinder (#4088) on center shelf between reagent holders as shown.
10. Place 25 mL sample tube (#9198L) alongside SpeedStir and place stirring bar (#6101) in sample tube.
11. Place SampleSizer® measuring tools (#6190 and #6191) on center shelf between reagent holders as shown.
12. When not in use, store pH color viewer (#6125T) behind Slim Lite with nameplate and color standards facing out.
13. Place *Pool & Spa Water Chemistry* booklet (#2004B) and Watergram® Water Balance Calculator (#6026) inside lab.
14. Plug Slim Lite and SpeedStir AC power adapter cords into outlet.

**Important:** Turn off Slim Lite and SpeedStir when not in use.

**Cleaning:** Wipe up fresh spills with damp cloth. Clean lab periodically with a mild soap and water solution.

