

DROP TEST SODIUM NITRITE (1 drop = 40 ppm)

Instr. #5011

COMPONENTS:

1 x 5011	Instruction
1 x 9198R	Sample Tube, Graduated (25 mL) w/ cap & red dot, plastic
1 x R-0819-C	Ferriin Indicator, 2 oz, DB
2 x R-0820-C	CAN Solution, 2 oz, DB

TO ORDER REPLACEMENT PARTS AND REAGENTS CALL TOLL-FREE
800-TEST KIT (800-837-8548).

PROCEDURE:

CAREFULLY READ AND FOLLOW PRECAUTIONS ON REAGENT LABELS.
KEEP REAGENTS AWAY FROM CHILDREN.

NOTE: When dispensing reagents from dropper bottles, **always** hold bottle in a vertical position.

Sodium Nitrite Test

1. Rinse and fill 25 mL sample tube (#9198R) to 5 mL mark with cooled (room temperature) water to be tested.
2. Add 4 drops R-0819 Ferriin Indicator. Swirl to mix. Sample will turn reddish orange (Fig. 1).
3. Add R-0820 CAN Solution dropwise, swirling and counting after each drop, until color changes from reddish orange to blue (Fig. 2).

4. Multiply drops of R-0820 CAN Solution by 40. Record as parts per million (ppm) sodium nitrite (NaNO_2).

NOTE: For results as nitrite (NO_2^-), multiply sodium nitrite (NaNO_2) concentration by 0.67.



Fig. 1



Fig. 2



31 Loveton Circle, Sparks, MD 21152 USA
800-TEST KIT (837-8548) • 410-472-4340

7/17